

Balancing Controller eb2000

Table housing

Type	Art. No.	Operation
eb2000-a	15114	automatic
eb2000-m	15115	manual

Description

The handy and sturdy controller with keypad and LC-display may be placed horizontally on a table or it may be mounted vertically to a wall (cabling ports available either on top or bottom). The controller allows weight positioning manually by pressing keys. The eb2000 automatic allows balancing either manually or automatically. Besides displaying digitally the spindle rpm the controller indicates the unbalance digitally in $\mu\text{m/s}$ and analog by bar graph (automatic filter adjustment).

Features

- Commutator or contactless type power transfer
- Simple handling
- Continuous unbalance display
- Continuous rpm display
- Manual balancing possible

